

SHOWER DRAINS



BASIC SQUARE DRAINS:

1. Install your standard 2" normal drain assembly.
2. Place Basic Square Drain Cover (loose).



HAWAII SQUARE DRAINS:

1. Install your standard 2" normal drain assembly.
2. Place Hawaii Square Drain Cover (loose).



ALL STAINLESS SQUARE DRAINS:

1. Install your standard 2" normal drain assembly
2. Leave your cover plate off.
3. Silicone your stainless drain in place making sure it sets all the way down.
4. Set basket in place.
5. Place All Stainless Square Drain Cover (loose).

